

TV Instructions



1. Turn on TV



2. If this screen comes up You are on android so continue To 3. if not and you see the screen on number 5., please continue from That point



3. Using these Outer buttons scroll across




4. Using TV remote, using The arrows, scroll to this Button, then you want to be Selecting HDMI1, press middle Button when HDMI1 is highlighted



5. You will see this screen



6. Using this remote, the circular area of the remote (outer for Up, down, left right) and Inner for select



7. Select Super Beams



8. Again, Using the circular area Of the remote (outer for Up, down, left right) and Inner for select



9. You will want to select "Live TV"



10. Using the cursor again select the genre on the left hand side, the middle will then give you a list of channels, using the circular area select the channel and press centre to select



11. The image of the programme will appear on the right hand side like this. To make this to the entire screen, just press the programme (in the centre) again.



12. You will then see the programme on the full screen



13. To go back to the programme list, press the back button then repeat

14. You also have the options of movies and series. To go back to number 9 you need to press the back button until you reach that screen then using the cursor select movies or series and follow same procedure at 10 onwards. If you scroll down further on Number 10, you Will see a selection in different languages.

Instrucciones de televisión



1. Enciende La TV

Si aparece esta pantalla
Estás en Android así que continúa
A 3. si no y ves la pantalla
En el número 5., continúe desde
Ese punto

3. Usando estos
Botones exteriores
desplazarse por

4. Usando el control remoto del
televisor, usando El círculo exterior,
desplácese hasta este Botón,
entonces quieres ser Seleccionando
HDMI1, presione el medio
Botón cuando HDMI1 está resaltado

5. Verás esta pantalla

6. Usando este control
remoto, el área circular del
control remoto (exterior
para Arriba, abajo, izquierda
derecha) e Interior para
seleccionar

7. Seleccionar Super Beams



8. Nuevamente, usando
el área circular del
control remoto (exterior
para arriba, abajo,
izquierda derecha) e
interior para seleccionar

9. Deberá seleccionar
"Live TV"

10. Usando el cursor nuevamente,
seleccione el género en el lado izquierdo,
el medio le dará una lista de canales,
usando el área circular, seleccione el canal
y presione el centro para seleccionar.
Sigue desplazándote por español

11. La imagen del programa
aparecerá en el lado derecho así.
Para hacer esto a toda la pantalla,
simplemente presione el programa
(en el centro) nuevamente.

12. A continuación, verá el programa
en pantalla completa.

13. Para volver a la
lista de programas,
presione el botón
Atrás y luego repita

14. También tienes las opciones de películas y series. Para volver al número 9, debe presionar el botón Atrás hasta llegar a esa pantalla, luego, con el cursor, seleccione películas o series y siga el mismo procedimiento a partir del 10. Si se desplaza hacia abajo en el Número 10, verá una selección en diferentes idiomas.